

## Instructions for Setting (and Changing) Your Personal Combination

1. Rotate lock dials to combination (original, factory setting is 0-0-0-5). Push button on crossbar to the right and completely remove u-shaped shackle from crossbar.

2. Rotate dust cover so that reference mark on right side lines up with reference mark on crossbar.

3. Insert setting tool into the two holes located between the button and dials on the crossbar. Push setting tool till you see and hear the button shift to the left. (You will hear a clicking sound.)

4. Remove setting tool and rotate dials to the new four-digit combination of your choice. Use a number that you will easily remember (birth date, telephone number, etc.).

5. Reinsert u-shaped shackle into crossbar. Your personal combination is now set. Without changing the combination check to make sure the button can be pushed to the right and the shackle removed from the crossbar.

6. If the button cannot be pushed to the right, or the shackle cannot be removed, set the dials to 0-0-0-5 (factory setting) and repeat steps 1-5. If you are still unable to set the combination, please consult Kryptonite or your dealer.

For your convenience, Kryptonite recommends setting your combination only once, with a combination you will easily remember. Save the setting tool and these instructions should you ever need to change your combination.

### Changing Your Combination:

\*To change your combination, repeat steps 1-5 using your new combination.

